ErP Product Information

Product name: 5G CPE

Model: H155-380

We, ZOWEE TECHNOLOGY (HEYUAN) CO., LTD. Declare under our sole responsibility that the above referenced product complies with the Directive 2009/125/EC, and its implementation regulation (EC) No 1275/2008 and (EU) No 801/2013. The external power supply complies with the implementation regulation (EU) 2019/1782.

AS of 1 January 2015, the following information for network equipment shall be visibly displayed on the manufacturers' freely accessible websites:

- a) For each standby and/or off mode and the condition providing networked standby into which the equipment is switched by the power management function or similar function:
- —the power consumption data in Watt rounded to the first decimal place,
- —the period of time after which the power management function, or a similar function, switches the equipment automatically into standby and/or off mode and/or the condition providing networked standby;

1 the power consumption of another condition:

Mode	power consumption (W)
Another Condition	0.5

2 Networked standby

Type of Network Port	Power Consumption of Networked Standby (W)	Time(min)
2.4G Wi-Fi	8.0	20
5G Wi-Fi	8.0	20
TEL	8.0	20
LAN	8.0	20
WAN	8.0	20
LTE	8.0	20
5G NR	8.0	20

AS of 1 January 2015, the following information for network equipment shall be visibly displayed on the manufacturers' freely accessible websites and user manual:

- b) The power consumption of product in networked standby if all wired network ports are connected and all wireless network ports are activated: 9.9 W.
- c) Guidance on how to activate and deactivate wireless network ports.

Type of wireless network ports	Guidance
	1. Connect your computer to the router's WiFi network
	(or connect the computer to the router's LAN port using
	an Ethernet cable). Open your Internet browser. Enter
2.4G Wi-Fi	192.168.8.1 in your browser address bar and log in to
2.43 WITI	your router's web-based management page.
	2. Choose Wi-Fi Settings > Wi-Fi Basic Settings. Click the
	2.4 GHz Wi-Fi, and choose to enable or disable the 2.4
	GHz Wi-Fi.
	1. Connect your computer to the router's WiFi network
	(or connect the computer to the router's LAN port using
	an Ethernet cable). Open your Internet browser. Enter
5G Wi-Fi	192.168.8.1 in your browser address bar and log in to
30 WITI	your router's web-based management page.
	2. Choose Wi-Fi Settings > Wi-Fi Basic Settings. Click the
	5 GHz Wi-Fi , and choose to enable or disable the 5 GHz
	Wi-Fi.